

Filling Instruction

Mouthpiece *25pcs + Device *25pcs



Step 1: Filling

1. Pre heat the oil before filling, but make sure not to pre-heat it higher than 122°F.
2. Filling needle's diameter must be 3.0mm or less.



Warning: Please fill the both oil tanks at the same time, or fill them in succession. After filling, make sure to get them capped no later than 2-3 minutes. Otherwise it might cause leakage.



Step 2: Capping

Please finish capping no later than 2-3 minutes after filling, which can avoid oil leakage effectively.

We recommend to fill and cap the devices one by one.