

# Filling Instruction

## In the box:

Mouthpiece \*25pcs + Device \*25pcs



## Step 1: Filling

1. Pre heat the oil before filling, but make sure not to pre-heat it higher than 122°F.

2. Filling needle's diameter must be 2.5mm or less.

To avoid overfilling, please fill 0.1ml or 0.2ml less. For example, if you were filling a 3ml disposable, you can fill 2.9ml or 2.8ml.

If you were filling a 6ml disposable, don't fill more than 5.8ml, otherwise it will cause overfilling easily.



## Step 2: Capping

Please finish capping no later than 2-3 minutes after filling, which can avoid oil leakage effectively.

We recommend to fill and cap the devices one by one.



Mind the direction of the mouthpiece. Make sure the stems be inserted into the holes on the silicone parts.